



P4804

Easy Series - Modules for False Ceiling

Remote control

GENERAL FEATURES

- SELECT AUX/TUN - To select between audio sources (the internal tuner and the external music channel, if available)
- ON-OFF - Switches the receiver operation on and off.
- SCN Scenarios
- SCAN - Used to make the tuner search for the next radio station
- STORE - Used for the manual memorising of the radio station that is being listened to in one of the 9 direct access.
- DEL - deletes the current memory.
- PR+ Change to the following memory
- VOL - To decrease the audio volume.
- Announcements
- VOL+ To increase the audio volume.
- PR- Change to the previous memory
- KEYS - Allow direct access to the tuner memories.
- JAZZ/BASS+ Jazz equalization / To increase the bass level.
- CLAS/BASS- Classic equalization / To decrease the bass level.
- POP/TREB+ Pop equalization / To increase the treble level.
- ROCK/TREB- Rock equalization / To decrease the treble level.
- AUX - To select aux audio source (jack 3.5 in volume control if available)
- FREQ - Direct frequency introduction in Khz (875-1080)
- IDEAL - Return to the pre-defined default values for Volume, Bass and Treble.
- SUPERBASS - Connection or disconnection of the SUPERBASS, bass reinforcement

TECHNICAL CHARACTERISTICS

INSTALLATION